

String Length



Description

This example determines the string length. There is no circuit required for this example. The example continues to add to the previous string.

Hardware

- Intel® Galileo

Instructions

1. Connect power supply to the Galileo and USB to USB Client Port on the Galileo.
2. Open Arduino IDE under Tools → Board select Intel® Galileo
3. Under Tools → Serial Port select the Com # where the Galileo is connected to.
4. Under File → Examples → 08.Strings and select the “StringLength” example.
5. Upload to the Galileo by clicking the upload button. 
6. Monitor the value of the potentiometer in the Serial Monitor. 
7. Input any string.

No Circuit Needed

